IMPORTANT!

READ THIS SHEET BEFORE INSTALLING YOUR BOARD!

Make sure that the power for both the Amiga AND your monitor is OFF before attempting to install the OpalVision card and plug in the monitor! Failing to do this may damage your Amiga and/or monitor!

Before installing your OpalVision Main Board, please note its serial number on your warranty registration card. This can be found on the white bar-coded sticker next to the Board's gold edge-connector fingers.

Although every OpalVision is tested before shipping, we highly recommend that you run the alignment adjustment program before using the OpalVision software. The program is run automatically when you install the OpalVision software. Follow the instructions listed on the screen carefully; the pot is in the back plate of the OpalVision card, above the video connector. If you have an Amiga 3000 or 4000, we recommend that you leave the cover of the computer off while doing this adjustment.

Do not attach ANY 2nd monitor or video device to the regular Amiga 23-pin video port while the OpalVision is installed, as doing so can overload the Amiga's video circuitry. See the Getting Started manual for full notes on the connection of multiple monitors.

OpalPaint includes full context-sensitive, on-line help accessible at any time by hitting the HELP key located between the main keyboard area and the numeric keypad. To find out about OpalPaint features added after the Reference Manual was printed:

Run OpalPaint

Hit OK in the initial "About OpalPaint" menu.

Move the pointer into the area above the row of coloured paint-pots.

 Hit the HELP key. The "OpalPaint Help Contents" page will appear after a short pause.

 Scroll down using the vertical scroll bar or the space-bar, and click on the button in front of the item marked "New OpalPaint Features".

Technical support and the latest versions of the software can be obtained on the OpalVision BBS. In the USA, phone (310) 787-4540.

Now, please follow the detailed instructions in the "Getting Started Manual" to install your hardware and software.